


MEMORY CARD MANUAL

Parts of the Memory Card



Before Using the Memory Card

This Memory Card requires a lithium battery to preserve data written to the card. Insert the lithium battery (CR-2016) or equivalent before using the Memory Card.

1. Inserting the lithium battery

Note: Since battery replacement **MUST** be done when the memory or program card is fully inserted into the Portfolio (otherwise you will lose stored data), it is good practice to install the first battery in a blank card in the following way:

- Insert card into unit. Follow guides for loading on card label.
- Find groove for removing battery holder (**top right rear edge** of card).
- Pull out holder. Place CR-2016 or equivalent lithium battery with (+) **DOWN** into holder. Slide holder back into card.

Caution: If plus (+) side is not facing **DOWN**, data will not be preserved.

2. Write-protect switch


When the write-protect switch is set to **ON**, data in the Memory Card is protected and cannot be over-written. Set the switch to **OFF** to write new data to the card, but keep it **ON** at all other times.

3. Replacing the lithium battery

The life of the lithium battery depends on the amount of data in memory and usage temperatures. Battery life is shortened by high temperatures over 112°F (40°C). To prevent loss of data, replace the lithium battery with the same type (CR-2016) or equivalent when the following terms expire:

- 32 kilobytes — 2 years
- 64 kilobytes — 1 year
- 128 kilobytes — 1 year

Caution: Data in the Memory Card will be lost if the lithium battery is simply removed from the card. **Always replace the lithium battery while the card is inserted in the main unit and the unit's power is on.**



Atari Corporation disclaims liability for changes, errors, or omissions. Reproduction of this document or of any portion of its contents is not allowed without the specific written permission of Atari Corporation.

Atari, the Atari logo, and Portfolio are trademarks or registered trademarks of Atari Corporation.

Copyright © 1989, Atari Corporation, Sunnyvale, CA 94086. All rights reserved.

Printed in Japan.

C103672-001 Rev. B